



Note

If CV joint boots are squeezed while being installed, a vacuum may be created inside the boot. This causes an inward fold in the boot during use. Lift the small diameter end of the boot after installing to equalize the pressure.

CV joint, outer
replace as complete set only
installing: insert circlip,
press joint on shaft until
circlip engages